



# Amalgam Pluggers / Condensers / Applicators




**1830**  
BEHRMAN (Fig. 1)



**1831**  
BLACK (Fig. 1-2)



**1832**  
MORQUETTE (Fig. 0/1)



**1833**  
Black Action 11/12 Plugger



**1834**  
Hollenback No. 1 Plugger



**1835**  
Hollenback No. 2 Plugger



**1836**  
Hollenback No. 3 Plugger



**1837**  
Blacks 0-1 (1mm-1.5mm)



**1838**  
Blacks 1-2 (1.5mm-2.5mm)



**1843**  
.7mm-1mm




**1839**  
Bodkin 1 (.7mm-1mm)




**1844**  
1mm-1.5mm




**1840**  
Bodkin 2 (1.5mm-2mm)



**1845**  
1.5mm-2mm



**1841**  
2.5mm-3mm




**1846**  
Oregon (Fig. 3)



**1842**  
Oregon 2



**1847**  
Oregon (Fig. 4)



**1848**  
UP 12



**1849**  
Applicator 1-2



**1850**  
Birtles Applicator Spatula



**1851**  
Birtles Applicator Spatula K



# Placement Instruments, Stopping Stoppers, Plug

## Placement Instruments



**1852**  
PICH (Calcium Hydroxide Placer)



**1853**  
CA


## Stopping Stoppers



**1854**  
Woodson 2



**1855**  
Woodson 3S



**1856**  
Woodson 3A



**1857**  
Woodson 3


## Pluggers




**1858**  
Pluggers 0-1




**1859**  
Pluggers 1-4



**1860**  
Pluggers 4-6



**1861**  
Pluggers 6-8



**1862**  
Black 1-2



**1863**  
Black 2-3




# Burnishers



1864  
Fig. 1



1865  
Fig. 28/29



1866  
Fig. 34



1867  
Fig. 27/29



1868  
Fig. 21B



1869  
ACORN  
Fig. 21



# Burnishers



1870  
21 Acorn



1871  
Fig. 21B




1872  
Fig. 2-34



1873  
Fig. 21C



1874  
Fig. 26-28



1875  
Fig. 2-30




1876  
Fig. 26-30



1877  
Fig. 27-29




1878  
PKT 1



1879  
Fig. 27-30



1880  
PKT 2




1881  
Fig. 34T



1882  
Fig. 3




1883  
PKT 3



1884  
PFI 21




1885  
PKT 3P



1886  
Pitts Pedo 19



1887  
PKT 4



1888  
Pitts Pedo 18



1889  
PKT 5

